




NZJF Foam Slurry Pump

Customer Services of Foam Slurry Pump



From left to right:



1. Texture Configuration of Impeller, Sheath and Cover Plate.
2. Shaft Seal
3. Bearing Assembly
4. Drive Type

Contact Us

Add: No.4 Industrial Rd., Shangrao Economic Development Zone, Shangrao City, Jiangxi Province, China
 Tel: +86-793-8469669 or +86-793-8457309
 Fax: +86-793-8461032
 Email: penghuafen@naipu.com.cn



Components of Foam Slurry Pump



Set of rubber wet ends

Contact Us

Add: No.4 Industrial Rd., Shangrao Economic Development Zone, Shangrao City, Jiangxi Province, China
Tel: +86-793-8469669 or +86-793-8457309
Fax: +86-793-8461032
Email: penghuafen@naipu.com.cn